

Owners Manual of 006 series and 007 series Keyfob Transmitter

Keystone's range of 006 & 007 series keyfob transmitters will work with Keystone's HRX006A receiver. The one, two button keyfob transmitter will also work with Keystone's HRX005 and HRX006 receivers.

HTX006/1, HTX007/1 is a one button transmitter.

HTX006B/2, HTX007/2 is a two button transmitter. Each button transmits to a different receiver channel. HTX006/2D, HTX007/2D is a double-push two button transmitter. Both buttons must be pressed down before the transmitter will transmit.

HTX006B/4, HTX007/4 is a four button transmitter. Each button transmits to a different receiver channel.

Coding

All 006 & 007 series transmitters come randomly pre-coded from the factory with one of more than 59,000 different codes. To match this code with the HRX006A receiver, adopt the following procedure :

- The HRX006A receiver has a self-learn function. Power up the receiver and press the "self-learn" button on the receiver pcb.
- With the transmitter at least one meter away from the receiver, press one of the buttons of the transmitter (or both if it is the HTX006/2D, HTX007/2D) so that a transmission is sent to the receiver.
- The code has now been learnt to the HRX006A receiver.
- For further details, consult the HRX006A manual.

Channel Transmission

006 & 007 series transmitters come pre-set to transmit to the following receiver channel.

	RX005A/B	RX005C	RX006	RX006A
HTX006/1, HTX007/1 Button One	channel 1	channel 2	channel 1	channel 1
HTX006B/2, HTX007/2 Button One Button Two	channel 1 ---	--- channel 2	channel 1 channel 2	channel 1 channel 2
HTX006/2D, HTX007/2D Button One and Two	channel 1	---	channel 1	channel 1
HTX006B/4, HTX007/4 Button One Button Two Button Three Button Four	--- --- --- ---	--- --- --- ---	--- channel 2 channel 3 ---	channel 5 channel 2 channel 3 channel 6

Keystone Electronics declare that the above equipment is in accordance with the 99/05/EC (R&TTE) directive.

OMTX0071